

tERA

Supervision and remote management services

CAREL



ENG











## Quick start guide

→ **LEGGI E CONSERVA  
QUESTE ISTRUZIONI** ←  
**READ AND SAVE  
THESE INSTRUCTIONS**

Integrated Control Solutions & Energy Savings




# CONTENTS

1 ACCESSING THE SYSTEM.....	5
2 tERA PORTAL.....	5
3 ADMINISTRATION.....	7
3.1 Registering a new subscription.....	7
3.2 Templates.....	7
3.3 Plant configuration  .....	10
3.4 Users.....	11
3.5 Communities  .....	12
3.6 Contact list  .....	12
3.7 Plant graphics  .....	13
3.8 GSM signal monitor  .....	15
3.9 Minister – service portfolio  .....	15
3.10 Multi-language management.....	16
4 tService  .....	16
4.1 Functions.....	16
4.2 Settings  .....	18
5 tTrace  .....	18
5.1 Getting started.....	19
5.2. Creating a report.....	19
5.3. Report actions.....	20
5.4. Scheduling a report.....	21
5.5 Customising a report.....	21
6 tDisplay  .....	21
Appendix A.....	22
Appendix B.....	25



## 1 ACCESSING THE SYSTEM


Using a web browser\*, go to the address provided by email and enter your system access credentials. Once the private portal has been created, requests to add new users must be sent to the system administrator and no longer to Carel. To change your password, go to the Users section.

\*The tERA portal is optimised to work with Google Chrome .

## 2 tERA PORTAL

After having logged in to the tERA portal, the home page is displayed. This features two sections:

- *Plants* section: this is displayed by default and contains all the installations (plants) created, even if they have not been completely configured.



The screenshot shows the tERA portal home page. At the top, there is a navigation bar with 'Home', 'Alarms', and 'Events' (with a red badge showing '2135'). A search bar and a user profile dropdown labeled 'Carel terasupport' are also present. Below the navigation bar, there are two tabs: 'Plants' (selected) and 'Applications'. The main content area displays three installation cards. Each card has a top-left corner with '0 alarms' and a red badge for 'events' (501, 0, and 1632 respectively). To the right of the event count are three icons: a megaphone for 'tDisplay', a wrench for 'tService', and a bar chart for 'tTrace'. The cards are titled 'Machine in Carel HQ', 'Energy Plant', and 'CRAC in lab. CAREL'. Each card includes a 'Devices:' section with a list of units: 'Unit 1' for the first, 'EM3 - 1' and 'EM3 - 2' for the second, and 'FLCORmCRCP' for the third. Small images of the respective equipment are shown on the right of each card.

For each installation, the icons in the top right corner indicate the active applications, while those at the top left notify users of any events and alarms. To access the details of an installation (in relation to a specific application), simply click the icon corresponding to the application.


- *Applications* section: this contains the list of active applications and corresponding associated installations. Simply click on an installation to access it.


The bar at the top of the page features the following sections:



The screenshot shows the top navigation bar of the tERA portal. It includes 'Home', 'Alarms' (with a red badge showing '86'), and 'Events' (with a red badge showing '4611'). A search bar and a user profile dropdown labeled 'carel terasupport' are also present.

On the left:

- *Home*: used to return to the Systems section;
- *Alarms*: contains the list of active alarms on all installations;
- *Events*: contains information on the most significant events on the portal.
- *Search*: search the installations bar using the text field and/or the advanced search filters available by clicking .



The screenshot shows the 'Advanced Search' form. It has a title 'Advanced Search' and a close button 'x'. Below the title are five input fields: 'Plant', 'Device', 'Application', 'Location', and 'Communities'. At the bottom right of the form is a blue 'Search Q' button.

On the right, next to the user name, is a drop-down menu with the following sections:

- *Profile*: provides direct access to the user's profile settings;

- *Event log*: lists all the events on the portal;
- *Administration*: contains the section relating to the configuration (if the user does not have tAdmin administrator rights, this section is not available);
- *Exit*: logout.

## 3.1 Registering a new subscription

In order to use a new subscription, the connection line needs to be registered (box, c.pco,...) under Administration – Register box. This can be done during system configuration (see the section on Plant configuration).

Choose the type of line and complete the following fields:

1. Tera box: serial number and security code shown on the connection box label;



2. c.pCO: MAC address, unique ID and tERA password, parameters available on the screen (ALARM+ENTER→Information→pCO info):



When clicking *Save*, the line or access point will be available during system configuration.

## 3.2 Templates

### 3.2.1 Creating a controller template

Access *Administration* -> *Templates*, click *new* and complete the required fields.

The *Template* field must be completed based on the type of connection device used.

The *Communities* field is used to associate the template to one or more groups. **Note that the template will be visible and modifiable by users of the community it is associated with, and will be visible to all the 'children', however not accessible for modification.** The template is always visible to users of a higher-level community (see the *Communities* section).

The description of the template can be managed in different languages (see the *Multi-language management* section).

Clicking *save* displays a new section for creating the variables; two modes are available:

1. Click *Import* and choose the file to import; the following file types can be imported:

Zip file (.zip) containing the .2cf and .2ct files created using 1tool. The offset parameter needs to be set correctly in order to ensure correct mapping of the integer variables. For this reason, check the value of the two variables, shown in the table, in the application:

1tool Protocol number	BMS_EXTENSION	Offset	MODBUS protocol Type	MODBUS protocol Address
3 (BMS1, PLAN) 5 (FIELDBUS1)	0	1	Coil Register (analog) Register (integer)	1 - 199 1 - 127 129 - 255
3 (BMS1, PLAN) 5 (FIELDBUS1)	1	2	Coil Register (analog) Register (integer)	1 - 207 1 - 207 209 - 415
30 (BMS1, PLAN) 50 (FIELDBUS1)	-	3	Coil Register (analog) Register (integer)	1 - 2048 1 - 5000 5002 - 10001
33 (BMS1, BMS2)	0	4	Coil Register (analog) Register (integer)	1 - 2048 1 - 127 129 - 10128
33 (BMS1, BMS2)	1	5	Coil Register (analog) Register (integer)	1 - 2048 1 - 5000 5002 - 15001
- (pCO WEB only)	-	6	Coil Register (analog) Register (integer)	1 - 2047 1 - 5000 5001 - 10000

**IMPORTANT:** If using Modbus over PLAN protocol, the offset must be set to 5.

Excel file (.xls). Exported from the DeviceCreator software or completed manually (template available together with the guide or on KSA - see the section on variable attributes).

**IMPORTANT:** If the Excel file is completed manually, the addresses of the integer variables must be entered with the offset already applied.

If offset = 1 or 4 → integer variable address = add defined in 2CF ("VAR\_INDEX") + 128



If offset = 2 → integer variable address = add defined in 2CF ("VAR\_INDEX") + 208

If offset = 3 or 5 → integer variable address = add defined in 2CF ("VAR\_INDEX") + 5001

If the import procedure is not successful, an error message will be shown, with the settings to be checked in order to fix the problem.

2. Use the editor on the portal. Click *new*, complete the fields relating to the variable and click *save*. See the section on Variable attributes for further information.




**IMPORTANT:** The addresses of the integer variables must be entered with the offset already applied.

The variables can be searched using the text filter and other advanced search filters. The  button can be used to display the user's favourite parameters, the  button is used to filter the variables based on different attributes.

### Variables

Name / Description    filter

Each template and each variable are associated with three buttons:


- *Edit* : to make changes,
- *Delete* : to delete the corresponding item,
- *Copy* : to create an identical copy of the element in question; in the case of variables, make sure the fields relating to the new variable are set correctly.

In both sections, multiple elements can be deleted together using the checkbox available on every row and the buttons at the top right.

### 3.2.2 Variable attributes

Below is a short description of the different attributes that can be associated with each variable:

- Code: unique identification code.

- Category: used to create groups of variables and simplify filtering and display. The existing categories can be used, or new ones created on the portal; to do this, in the variable editor, click  next to the category field and add the description. Once the new category has been saved, it will be available in the corresponding combo box.



- **Description:** description of the variable.
- **Address in:** address occupied in the device's memory.
- **Address out:** specify only if different from the input.
- **Variable type:** Digital, Alarm, Integer, Analog.
- **Frequency:** sampling frequency in seconds; values supported are 5, 30, 180, 900.
- **Bit position:** first bit position of the variable (for example: bit 0 for a low-byte variable, bit 8 for a high-byte variable).
- **Variable length:** effective length of the variable (for example: 16 bits if it occupies one complete word, 1 bit typically for alarms).
- **Variable size:** size of the register holding the variables (8, 16, ...), expressed in bits.
- **Priority:** for alarm variables only, sets the priority for alarm management on the supervisor; values supported: Technical, Very High, High, Medium, Low.
- **Number of decimals:** number of decimal numerals.
- **Sign:** if enabled, the variable will be displayed with the + or - sign (1 = signed, 0 = unsigned).
- **Maximum value:** maximum value of the variable.
- **Minimum value:** minimum value of the variable.
- **Unit of measure:** unit of measure to be displayed next to the variable.
- **Modbus read function:** Coil or Digital Input for digital and alarms. Holding or Analog Input for analogue and integer.
- **Modbus write function:** Single Coil for digital and alarms; Single Holding for analogue and integer.
- **Read/write:** defines the type of access allowed to the variable, read-only or read/write.
- **Access level:** possible values: OEM, service and user, where each group includes the following one, in the order stated. Used to create groups of variables and limit their visibility based on the access level of each user.
- **Linearisation parameters: A-value and B-value:** the variable value will be calculated as  $y = a * x + b$ ; where x is the sampled value and y the value indicated in the portal.
- **Display:** attribute only available when using an Excel file to create the template; establishes whether a variable is considered a favourite and therefore displayed in the corresponding section. [Home, Main, Stat = favourite].
- **Thresholds:** attribute only available when using the editor on the portal to create the template. See the section on Alarm management by threshold.


### 3.2.3 Alarm management by threshold

An alarm can be generated and notification sent when the value of a certain analogue or integer variable changes. To do this, simply complete the Thresholds section in the template for the variable in question.

For each variable, the following can be set:

- Low threshold;
- Low threshold hysteresis;
- High threshold;
- High threshold hysteresis;

When the value of the analogue or integer variable falls below the low threshold or exceeds the high threshold, an alarm is activated; the event ends when the value rises back above the low threshold + hysteresis or falls back below the high threshold – hysteresis.




### 3.3 Plant configuration

Access *Administration*, go to the *Plants* section, click *new*, and complete the fields.

All the data and any notifications relating to the installation refer to the time zone set here.

The communities field is used to set the limits for accessing the installation (see the Communities section). The installation can be associated with multiple communities. The installation can be assigned an image that is then displayed on the Plants page; at end of the procedure, click *save* to make the new installation visible in the list.

To associate a line with the installation, click *lines*  and then click *new*.

In the *serial number* field, choose the ID of the connection line that will be used. Only the devices that have been registered and are not used will be shown in the list.


In addition, a new connection line can be registered and associated with the installation using the *Register* button.

Complete the fields:


- Protocol type: type of serial protocol. [Modbus, Modbus over Plan, Carel, c.pco].
- Bitrate: Bitrate set on the serial line.
- Data bits: number of data bits set on the serial line.
- Parity: parity set on the serial line.
- Stop bits: number of stop bits set on the serial line.
- Box pLAN Id: Id of the box in the pLAN network.

**IMPORTANT:** The parameters set here must coincide with those set on the physical devices so as to enable communication. Otherwise, the OFFLINE alarm will be shown, indicating a communication error.

The c.pco is at the same time both a connection line and device, and can automatically transfer all of its settings to the tERA server. Consequently, the protocol parameters should not be set; selecting the “create device” flag creates the device automatically.




Once the line has been configured, click *save*. To add additional lines, repeat the operation.

To allocate a controller to the installation, click the *dispositivi*  button under the *Plants* section or the *lines* section and then click *new*. Complete the fields:


- Name.
- Description.
- Line: select the line that the device is physically connected to. This field is not required, it can be associated subsequently, meaning it is possible to first create the devices and then, from the list of devices, select several of these and use the *Configure line* button to create a multiple association.
- Template: select the one of the list of controller variables. The list shows the existing variables.
- Address: the device's serial address.

Click *save* to save the settings.



To view the list of the variables, click *variables* . The default settings (entered in the template) can be set for each individual device using the  button for each variable. Only the name, description, unit of measure, frequency, priority and alarm thresholds can be changed.

**IMPORTANT:** It is recommended to start from a template that is as close to the final version as possible. Once a template is being used, it can no longer be modified, which prevents the introduction of global modifications.

To add further controllers, repeat the operation. Each box supports a maximum of 10 devices.

To edit an installation, a line or a controller, click the corresponding *edit*  button.

Plant configuration is now complete.








The  icon shown in the row corresponding to the installation (plant) that has just been created indicates that configuration is in progress: the configuration needs to be loaded in order to make it active; to do this, from the lines section, select . Likewise, whenever changes are made to the plant configuration, the configuration needs to be loaded again to make it active.

The loading process is completed when the yellow icon is no longer shown. The installation is thus active and available in the Home page. If an error occurs, see the Events log section for information on the causes.

Administration / Plants

## Plants

Code / Description filter + new delete

	Code	Description	operations
<input type="checkbox"/>	demo plant	Machine in Carel HQ	  <span>lines</span> <span>devices</span>
<input type="checkbox"/>	FLCORmCRCP	CRAC in lab. CAREL	  <span>lines</span> <span>devices</span>
<input type="checkbox"/> 	Energy Plant	Energy Plant	  <span>lines</span> <span>devices</span>

### 3.4 Users

To manage system users, from the drop-down menu on the bar at the top, select *Administration* then *Users*.

To create a new user, click *new* and complete the required fields:

- the *username* and *password* fields are used to access the portal.
- The *E-mail* field is not required, rather it is used to complete the contact details that are automatically added to the contact list when each new account is created. The contact details can also be completed subsequently.
- *Language*: the items on the portal and the descriptions of the elements created (installations, templates, variables, ...) will be displayed in the user's language, if available, otherwise the default language will be used.
- *Profile*: establishes the functions available to the user:
  - Administrator: maximum rights for all applications.
  - User: limited functions for all applications.

Based on the application, administrator users can access the following functions:

tService: pco upgrade  
 menu settings: configuration of scheduled reports and alarm notifications  
 tTrace: Creation of new templates  
 Report scheduling  
 tDisplay: User profile only  
 tAdmin: Access to the entire Administration section

- Community: allocating users to a community limits their access rights and visibility to the installations, templates and users allowed for that group. A user can belong to more than one community..
- Access variable for reading: defines the set of variables that will be visible to the user.
- Access variable for writing: defines the set of variables that can be written by the user.

Once the settings have been completed, click *Save* to make them active.

By default, a user can access all the applications available on the portal using the functions relating to their profile. Click the Profiles button to manage the available combinations in the profile list: disable access to certain applications, grant administrator access for certain applications, and user access to others, etc.

Profiles x

tWebServices - User +

tAdmin	Minister	
tTrace	User	
tTrace	Administrator	
tService	Admin	
tDisplay	User	
tService	User	
tAdmin	administrator	

x close

**IMPORTANT:** the Minister profile must always be added manually by other users who already have this profile.

To change the password, access *Profile* from the drop-down menu on the bar at the top of the portal; the password must contain at least 8 characters.

### 3.5 Communities


Communities are used to limit access to and visibility of the elements available on the portal.

These represent a way of organising the data by creating groups of users and systems; a user or installation can belong to one or more communities, however the users in a certain community can only view and access the defined installations and users.

On the tERA portal, a default community is automatically created and cannot be edited or deleted. This community is the parent of all the communities that are then created subsequently, making up a tree structure in which each community can access all the elements relating to its child communities.

To create a community, from the drop-down menu on the bar at the top, access *Administration* then *Communities*, click *new* and complete the fields. The parent community that the new group belongs to must always be specified.


If a community has child communities, it cannot be deleted. Consequently, the *delete* button in the list of communities is disabled; first the child communities need to be deleted, then the button will be enabled.



### 3.6 Contact list

This section contains all the contacts on the portal that can be displayed and used when configuring alarm notifications and sending reports.

Whenever a user is created, the system automatically adds the corresponding contact details to the contact list. If the *E-mail* field is completed when creating a user, the contact will contain the specified email address, otherwise it can be added later.

To do this, from the drop-down menu on the bar at the top, access *Administration* and then select *Contact list* and click .

Different types of addresses can be added, without limits; the contact details relating to each user are deleted when the user is deleted.

Additional external contacts can be added to the portal using the *new* button.

### 3.7 Plant graphics

The view of each installation and/or unit can be customised with .html graphic elements by administrator-level users. For the use of this function, users are assumed to have knowledge of html and JavaScript.

To customise the display, from the drop-down menu on the bar at the top, access *Administration* and then select *Plant graphics*. Click *new*, complete the fields and click *save*. A new row will then be displayed in the list. Click the *Configuration* button to access a new page, featuring two sections:

- on the left, the *Components* section, where the *new* button lists all the elements that make up the graphic interface (images, html, js, css, ...). A single .zip file containing all the required files can be used. The default .html file needs to be selected using the checkbox.

**IMPORTANT:** The .zip file must respect the same directory structure shown in the HTML code for the correct definition of the paths and display of the layout. As a reference, in the example shown in Appendix A the .zip has all the files in the root, there are no directories (example downloadable from KSA).

- on the right, the *Associations* section, specifying how to introduce the graphic interface. The associations can be made at a template, device and/or installation level. If being made by template, the interface is introduced on all devices that use the specified template, otherwise it is introduced for the individual the devices and/or installations specified.

Once both sections have been completed, accessing the corresponding installations opens a new tab called *Layout*, organised at an installation and/or device level, depending on the established associations.

tERA provides ready-to-use utilities, which can be referenced as follows:

```
<script src="{CP_JS}/jquery.min.js"></script>
<script src="{CP_JS}/jquery-ui.min.js"></script>
```

To use standard jquery functions.

```
<script src="{CP_JS}/custom-pages.js"></script>
```

Function for reading and writing variables.

Styles used by the previous files:

```
<link href="{CP_CSS}/jquery-ui.min.css" rel="stylesheet" />
<link href="{CP_CSS}/custom-pages.css" rel="stylesheet" />
```

The css and js files created by the user, together with the images, must be referenced using the following tags, to ensure correct operation:

```
<link href="{CSS}/style.css" rel="stylesheet" />
<script src="{JS}/script.js"></script>

```

The following tags are used for operations on the variables. The *custom-pages.js* file is responsible for parsing *var-placeholder* elements. If the variable is read/write, when clicking its area, a popup opens automatically for entering the value to write.

If wanting to introduce custom pages at a device or template level, the tags shown in the following example can be used. The system parses the information automatically:

```
<div class="var-placeholder" data-line-ident="{LINE_IDENT}" data-line-type="{LINE_TYPE}" data-device-serial-
address="{DEVICE_SERIAL_ADDRESS}" data-variable-code="Probe_1"></div>
```

An installation (plant) can have two or more boxes, and this prevents the tags from being parsed automatically. If wanting to introduce custom pages at an installation level, the values of the different attributes need to be explicated for correct operation, as shown in the following example:

```
<div class="var-placeholder" data-line-ident="RVRBX00G00-D0000100" data-line-type="TBOX_WIRELESS" data-device-serial-address="1" data-variable-code="Probe_1"></div>
```

If using an Ethernet box, enter code RVRBX00E00 in the *data-line-ident* field, and the TBOX\_ETHERNET tag in *data-type-line*.  
If using the c.pco, enter the MAC address without decimal points in the *data-line-ident* field, and C\_PCO in *data-type-line*.

Appendix A shows an example of an .html page for customisation. Other examples can be downloaded from KSA: <http://ksa.carel.com/group/tera1/custom-pages>

The browser creates a copy of visited pages in its own memory (called the cache). In the event of problems displaying the custom page after having made changes, it is recommended to clear the browser cache.

The following web services are made available for operations on the variables:

Read variable:

**url:**  
*custom-pages/cp/services/{line identifier}/{line type}/{device serial address}/{variable code}/load*  
**method:**  
GET  
**result:**  
{  
    idDevice: 2,  
    idModelVariable: 2,  
    lineIdent: 'RVRBX00G00-A000123',  
    lineType: 'TBOX\_WIRELESS' or 'TBOX\_ETHERNET' or 'C\_PCO',  
    deviceSerialAddress: 1,  
    variableCode: 'var-code',  
    canModify: 'true/false',  
    name: 'var-name',  
    value: 'variable value',  
    uom: 'C°',  
    type: 'bool' or 'decimal' or 'int' or 'alarm'  
}

Write variable:

**url:**  
*custom-pages/cp/services/devices/{idDevice}/variables/{idModelVariable}/save*  
**parameters:**  
value  
**method:**  
POST  
**result:**  
if ok {  
    "success": true }  
else {  
    "success": false,  
    "error": "Error message"  
}

Appendix B shows some simple functions that demonstrate the use of these URLs.

### 3.8 GSM signal monitor

This section is used to check GSM signal strength. The GSM status column shows the average communication quality: low, medium, excellent. Click on [View](#) to view the trend in signal quality in more detail, for further information. To get the latest data, click on [Update data](#). The chart is refreshed automatically once the samples are received by the server. During communication between box and server, sampling data is not available, and is represented by a section in a different colour between two circles. Click the date button to see information relating to a specific day or days. The chart shows the values as a percentage of the optimum value, and shows the data for the entire day.

### 3.9 Minister – service portfolio

This section of the administration area is used to manage subscriptions and verify related costs, with the possibility to check consumption and modify the configuration for each subscription. Clicking [Configuration](#) for each subscription accesses:

Administration / Service Package /

**Plant** demo plant  
**Line** RVRBX00E00-D0000003  
**Line Type** TBOX\_ETHERNET  
**Registration Date** 2013-May-07 16:29:17

[Management](#)   [Configuration log](#)   [Usage data](#)

- Subscription management with the option to activate / deactivate services and check thresholds

Application			Feature		
Active	Application	Operation	Status	Feature	Operation
✓	tTrace	<a href="#">Deactivate</a>	✓	pCO SW update	<a href="#">Deactivate</a>
✓	tService	<a href="#">Deactivate</a>	✓	Live recording	<a href="#">Deactivate</a>
✓	tDisplay	<a href="#">Deactivate</a>	✓	Logging frequency	<a href="#">Deactivate</a>
✓	tWebServices	<a href="#">Deactivate</a>	✓	Variable update	<a href="#">Deactivate</a>
			✓	Logged variable	<a href="#">Deactivate</a>

The table below shows the limits available for the functions included in the basic subscription:

Function	GPRS threshold	LAN threshold
Read and write variables with manual request by user	tService: 100,000 tDisplay: 5,000 updates /month	tService: 100,000 tDisplay: 5,000 updates /month
Automatic variable logging	30 variables	300 variables
Variable logging frequency	30 seconds	5 seconds
Live recording duration (every 5 seconds) of installation variable trend	1 hour/month	10 hours/month
pCO SW update	0 month	0 month


If needing to extend these limits, the corresponding feature needs to be activated.

- Control subscription configuration history
- Control monthly consumption

If required, one or more additional services can be activated for one day only.


To extend these functions to other users, under *Administration - Users*, click *Profiles* and add the corresponding option to the existing list.

### 3.10 Multi-language management

Some of the descriptions on the display can be managed in different languages: descriptions of the templates, descriptions of the variables, codes and descriptions of the installations and devices, names of new categories... Where available, the  button expands a list used to enter information in the desired languages.

The following languages are supported:

**Description:**


English (US) 	
Italiano	Deutsch
Español	Français
中文	Türk
Svenska	


The language displayed depends on the language of the user who has accessed the portal.

If the descriptions only feature one language, then that language is always displayed, irrespective of the language of the logged in user. If the language of the logged in user is not supported, the default language is used.























This application makes maintenance faster and more effective by analysing installation operation via a remote connection and improving service levels by reducing troubleshooting times.

Access the installation from the home page by clicking  tService






The screenshot shows the tService web interface. At the top, there is a navigation bar with 'Home', 'Alarms', 'Events', and a search bar. The user is logged in as 'Administrator'. The main content area is titled 'View all plants' and shows a list of plants: 'tera-demo-plant' and 'd3-tera-demo-1 (1)'. The 'tera-demo-plant' is selected, and the 'Variables' tab is active. Below the tabs, there is a search bar and a table of variables.

<input type="checkbox"/>	★	Code	Description	Device	Value	UoM	Actions
<input type="checkbox"/>	★	Protocol	Protocol	d3-tera-demo-1			 
<input type="checkbox"/>	★	mDIGITAL_4	?null_en?	d3-tera-demo-1			 
<input type="checkbox"/>	★	Enable_Read_4	Probe Enable 4	d3-tera-demo-1			 
<input type="checkbox"/>	★	mDIGITAL_3	?null_en?	d3-tera-demo-1			 
<input type="checkbox"/>	★	mDIGITAL_2	?null_en?	d3-tera-demo-1			 
<input type="checkbox"/>	★	Enable_Read_1	Probe Enable 1	d3-tera-demo-1			 
<input type="checkbox"/>	★	Probe_1	Analog input 1	d3-tera-demo-1		C	 
<input type="checkbox"/>	★	ANALOG_7	?null_en?	d3-tera-demo-1			 
<input type="checkbox"/>	★	mDIGITAL_1	?null_en?	d3-tera-demo-1			 
<input type="checkbox"/>	★	Probe_4	Analog input 4	d3-tera-demo-1		C	 

### 4.1 Functions

The default view shows the data for the entire installation, displayed in four tabs (five if there are custom pages):








- *Variables*: this shows the list of all the installation variables. Click  to read the variable in real time, and  to write the value, if the variable is configured accordingly. To read multiple variables, check on the checkboxes and then click  at the top right.

The list of variables is arranged automatically using the filter buttons corresponding to the categories available for the current template.


Click the star  to add the variable to the group of favourites.

The variables can be sorted by code and description by clicking the headings on the corresponding columns.

- *Alarms*: by default the data is accessed in *active* mode, listing all the active alarms on the selected controller, in chronological order. The colour shown on each row represents the alarm priority. The *Ack*  and *Reset*  buttons are used to acknowledge and reset the alarm. The alarms are only reset at a portal level, an not physically.

To access the alarm log for the controller, click  . The alarms can be filtered for a certain period of time using the *start time* and *period* fields, and then clicking .







The alarms can be sorted by priority, description and date, by clicking the headings on the corresponding columns.

- *Trends*: by default the data is accessed in *log* mode, showing the charts of logged data. The logged data can be displayed over a *daily*, *weekly* or *monthly* period starting from chosen date; the current day is shown by default. To select a specific period, use the *start time* and *period* fields and click .

**IMPORTANT:** To be able to display the data relating to a variable on the chart, the frequency field needs to be set to a value other than zero.

To configure the chart click .

A specific period on the chart can be displayed with greater detail (zoom) by selecting it directly with the mouse. Click  to reset the zoom.

Clicking   switches to *live* mode, so as to perform sampling every 5 seconds and see the evolution of the data on the chart instantly, clicking  to start,  to stop or  to delete the chart. Click  to select the variables to sample. Any variable available in the template can be sampled.

- *Report*: used to export installation data in Excel format. Select the required variables, the period and date, and the frequency of the data in the file.. Only logged variables will be included in the report. The following table shows the possible combinations:

tService reports limits		
Report period	Available frequencies	Number of variables
Daily	5, 30, 60, 180, 300, 600, 900	10 with exception of the 5 second frequency, where is it possible to export 2 variables
Weekly	300, 600, 900	10
Monthly	900	10

To access specific devices in the installation, simply click them in the menu on the left.





The same tabs are displayed, only the information now relates to the individual device.



**IMPORTANT:** the data are automatically sent at the following intervals:

**GPRS box:** only if there are variables sampled with a frequency of 30 seconds or higher, the data are sent automatically to the server every 12 hours. If there are variables sampled every 5 seconds, the related data are sent every 3 hours, and all the other variables are transferred every 6 hours.

**LAN box:** all the variables are automatically sent to the server every 30 minutes.

The data on the box and on the server can be aligned whenever desired by clicking , available only at a device level in the trends tab. See the Event log section to check transfer status. The page also needs to be refreshed (F5 or ) to update the chart with the new data received.


The following feature is available at a device level:

- *Update Pco*: this section is used to update the software on pCO controllers. Create a zip file containing the necessary files and then select this by clicking . The files will be located in the corresponding sections: *Mask* (.iup file), *Strategy* (.blb/.bin/.blx files) and *Setting* (.development file). Click .

**IMPORTANT:** it is strongly recommended to see the FAQ on 'Commissioning Tool – Serial port configuration' in 1tool to check the serial ports and BIOS versions required for correct operation.

**IMPORTANT:** it is strongly recommended to upload a .dev file corresponding to the specific application together with the application files.

Clicking on View all plants in the menu on the left accesses the alarm KPI for all the installations over the last month:




## 4.2 Settings

Only visible to tService administrator-level users, and comprises the following options:

### 4.2.1 Alarm notifications

Notifications can be received via email whenever an alarm is activated. To create a new notification rule, click *New*. The notification settings are divided into three sections:

- *Rule*: select or deselect the *Enabled* flag to activate or deactivate the rule. To receive notification not only when an alarm is activated, but also when it is no longer active, select the corresponding *Notify alarm termination* flag.

In the *priority* section, establish the priority or priorities of the alarms that are notified, choosing between .

The *Selection* field is used to specify the level for sending notifications: all the installations in a community, an individual installation or an individual device.

- *Notifications*: this section defines the contacts who are notified of the alarms.

- *Time band*: this section determines the time period for sending notifications. Once all the sections have been completed, click *Save* to make the settings active.

### 4.2.2 Reports

The logged variables can be exported and downloaded from the portal and/or sent via email. This section features two tabs:

- *Report template*: defines a set of variables. Click *New* and complete the fields.

- *Report scheduler*: click *New* and complete the fields to schedule a new report. Select the required template, the period, the export time and corresponding time zone, and the frequency of data in the report.



tTrace is a high level analysis service and an advanced reporting tool for comparison between different installations, used to highlight the best configurations and optimise configuration.

## 5.1 Getting started

Firstly, select a community from the drop-down menu at the top left. If wanting to create a report for a sub-community, it is strongly recommended to access this sub-community so as to have the same visibility as the end user and guarantee access to the data.


The directory structure is shown on the left, with the following contents:

Root: currently selected community

- Communities: this directory contains all the sub-communities of the selected community. It should be noted that each organisation has the same directory structure.

- Reports:


- My reports: existing templates and reports.
- Resources: logos for customising the reports



## 5.2. Creating a report

1. Select the template: in my reports, click an available template:


- Dashboard: four individual charts in one single report
- Single chart: Comparison of data from different installations over different periods



2. Configure the report: on the new page, click Options at the top right to enter the report settings.



To make the configuration process faster, if there is a similar existing report, this can be loaded automatically by selecting it from the drop-down menu at the top and then modifying the settings as necessary.



Reports can be created for complete installations, templates (all the devices with the same template will be displayed) and individual devices. These fields can be used individually or in combination to filter the desired variables to include in the report. The variables can also be filtered by unit of measure. All these fields allow multiple selection.

In the Time range field, a number of default periods are available. The interval can also be selected freely, specifying the start and end date.

Using the Reference date field, a second time period can be added to the chart for comparison. The same Time range set will be displayed.

3. Save and generate: once all the fields have been entered, it is recommended to save the report and then click OK to generate it.

Use the Export button to export the report in the different formats available.



When the report has been saved, it will be displayed underneath the corresponding template in the My reports section.

Carel's Headquarters

Single chart Data refreshed May 2, 2014 at 3:00:27 PM

Folders		Repository		Sort By: Name   Modified Date			
Carel's Headquarters descr	Run	Edit	Open	Copy	Cut	Paste	Delete
Organizations							
Reports							
My Reports							
Resources							
Name	Description	Type	Created Da	Modified D:			
Dashboard	Four single charts in a unique report	Report	April 29	April 11			
Single chart	Compare data from different plants on different perio	Report	April 29	April 11			
Demo plant 1		Report Version	April 30	Today			
Example 1		Report Version	April 30	April 30			
Model demo report		Report Version	April 30	April 30			

### 5.3. Report actions

Select a report in My reports and click the right mouse button to access the possible actions available.

Name	Description	Type	Created Date	Modified Date
Dashboard	Four single charts in a unique report	Report	April 29	April 11
Single chart	Compare data from different plants on different periods	Report	April 29	April 11
Demo plant 1		Report Version	April 30	Today
Example 1		Report Version	April 30	April 30
Model demo report		Report Version	April 30	April 30
Options		Report Version	April 29	April 29
Demo plant 1		Report Version	Today	April 30

## 5.4. Scheduling a report

Select the report in My reports and click the right mouse button. Select Schedule. A new page is opened, showing all the report scheduling options.

Click Create schedule and complete the settings in all the sections:

- Schedule: enter the start and end time, the time zone and the number of repeats of the report, which may be basic (every n minutes, hours, days, weeks) or custom (selected months, days, ...)
- Parameters: modifications can be made to already created reports.
- Output options: define the output file name, language, format, ...
- Notifications: configure email notifications.

Once all the sections have been configured, click Save. The scheduling settings will now be active.

## 5.5 Customising a report

The Resources - Images directory contains predefined images added to the reports. These can be replaced by selecting them and then clicking the change button.

Each community can customise reports by adding new images to the corresponding Resources directory.



Basic application with customisable interface to monitor installation data in real time and change the settings via a remote connection.

Once having accessed the desired installation, two tabs are displayed (three if custom pages have been created):

- *Variables*: this shows the list of all the controller variables for read and write Alarm 1 Enable operations.
- *Alarms*: this section shows all the active alarms in the installation. The colour of each row represents the alarm priority.

By default, the menu on the left is hidden. To display it, click .

If there is only one device in the installation, this is accessed directly, without needing to go through the installation level (default setting).

Use the - - buttons to change the number of variables shown on each page.

Example custom .html page:

```

<!doctype html>

<html lang="en">
<head>
  <meta charset="utf-8">
  <title>Custom Page Simulator</title>
  <link href="{CP_CSS}/jquery-ui.min.css" rel="stylesheet" />
  <link href="{CP_CSS}/custom-pages.css" rel="stylesheet" />
  <link href="{CSS}/simulator.css" rel="stylesheet" />
</head>

<body>
  <div id="div-index" class="div-container">
    <section id="main-container">
      <div class="preview-container"><a href="#div-livingroom"></a></div>
      <div class="preview-container"><a href="#div-kitchen"></a></div>
      <div class="preview-container"><a href="#div-bathroom"></a></div>
      <div class="preview-container"><a href="#div-bedroom"></a></div>
    </section>
  </div>

  <div id="div-livingroom" class="div-container" style="display: none;">
    <section id="room-container">
      <a href="#div-bedroom" class="row-link"><div class="row-container left-row">&lsquo;</div></a>
      <div class="img-container"></div>
      <a href="#div-kitchen" class="row-link"><div class="row-container right-row">&rsquo;</div></a>
    </section>

    <div class="main-btn"><a href="#div-index"></a></div>

    <div class="variable-btn livingroom var-placeholder" data-line-ident="{LINE_IDENT}" data-line-type="{LINE_TYPE}"
data-device-serial-address="{DEVICE_SERIAL_ADDRESS}" data-variable-code="Probe_1"></div>
  </div>

  <div id="div-bathroom" class="div-container" style="display: none;">
    <section id="room-container">
      <a href="#div-kitchen" class="row-link"><div class="row-container left-row">&lsquo;</div></a>
      <div class="img-container"></div>
      <a href="#div-bedroom" class="row-link"><div class="row-container right-row">&rsquo;</div></a>
    </section>

    <div class="main-btn"><a href="#div-index"></a></div>

    <div class="variable-btn bathroom var-placeholder" data-line-ident="{LINE_IDENT}" data-line-type="{LINE_TYPE}"
data-device-serial-address="{DEVICE_SERIAL_ADDRESS}" data-variable-code="Probe_2"></div>
  </div>

  <div id="div-bedroom" class="div-container" style="display: none;">
    <section id="room-container">
      <a href="#div-bathroom" class="row-link"><div class="row-container left-row">&lsquo;</div></a>
      <div class="img-container"></div>
      <a href="#div-livingroom" class="row-link"><div class="row-container right-row">&rsquo;</div></a>
    </section>

    <div class="main-btn"><a href="#div-index"></a></div>

    <div class="variable-btn bedroom var-placeholder" data-line-ident="{LINE_IDENT}" data-line-type="{LINE_TYPE}"

```

```
data-device-serial-address="{DEVICE_SERIAL_ADDRESS}" data-variable-code="Probe_3"></div>
</div>
```


```
<div id="div-kitchen" class="div-container" style="display: none;">
  <section id="room-container">
    <a href="#div-livingroom" class="row-link"><div class="row-container left-row">&lsaquo;</div></a>
    <div class="img-container"></div>
    <a href="#div-bathroom" class="row-link"><div class="row-container right-row">&rsaquo;</div></a>
  </section>
```

```
<div class="main-btn"><a href="#div-index"></a></div>
```

```
<div class="variable-btn kitchen var-placeholder" data-line-ident="{LINE_IDENT}" data-line-type="{LINE_TYPE}"
data-device-serial-address="{DEVICE_SERIAL_ADDRESS}" data-variable-code="Probe_4"></div>
</div>
```

```
<script src="{CP_JS}/jquery.min.js"></script>
<script src="{CP_JS}/jquery-ui.min.js"></script>
<script src="{CP_JS}/custom-pages.js"></script>
<script src="{JS}/simulator.js"></script>
```

```
</body>
</html>
```







## Appendix B

Function for assigning a variable value to a variable:

```
function test() {
var url = "/custom-pages/cp/services/${LINE_IDENT}/${LINE_TYPE}/${DEVICE_SERIAL_ADDRESS}/VARIABLE_CODE/load";
$.get(url, function(data) {
    var value = data.value;

    if (value < "x") {
        //do something
    }
});
}
```

In this example, only the value of the variable returned by the web service is used. Remember that additional information can also be retrieved, such as the type of line, serial number, type of variable,... (see json format in the Plant graphics section)

Function to execute a check on the value of two variables:

```
var EN_Z03;
var EN_Z04;

var URL_EN_Z03= "/custom-pages/cp/services/${LINE_IDENT}/${LINE_TYPE}/${DEVICE_SERIAL_ADDRESS}/EN_Z03/load";
$.get(URL_EN_Z03, function(data) {
    EN_Z03 = data.value;

    compareVariables();
});

var URL_EN_Z04= "/custom-pages/cp/services/${LINE_IDENT}/${LINE_TYPE}/${DEVICE_SERIAL_ADDRESS}/EN_Z04/load";
$.get(URL_EN_Z04, function(data) {
    EN_Z04 = data.value;

    compareVariables ();
});

var compareVariables = function() {
    if (EN_Z03 && EN_Z04) {
        if (EN_Z03 === 1 && EN_Z04 === 1) {
            //do something
        } else {
            //do something else
        }
    }
}
```





# CAREL

CAREL INDUSTRIES SpA

Via dell'Industria, 11 - 35020 Brugine - Padova (Italy)

Tel. (+39) 049.9716611 Fax (+39) 049.9716600

<http://www.carel.com> - e-mail: [carel@carel.com](mailto:carel@carel.com)

